

#7022 AE & KYG

1. Note approx. spring setting before removing anything.
2. Remove spring, stock collar and screw.
3. Place R.P.M. Top Ring(round) on top of spring and install the spring back on shock.
4. Grip the edges of Top Ring and pull down to add or remove additional clips.
5. Keep the thickest clips near the top of the shock.

#7022 AE & KYG

